

# L'identification de substances narcotiques

Les tests d'identification NARK®II permettent à l'enquêteur d'identifier facilement et rapidement les substances suspectées d'être des drogues, narcotiques ou/et hallucinogènes.

Chaque test comporte une codification colorimétrique. Les réactifs chimiques sont conditionnés dans des ampoules en verre scellées. Prêts à l'emploi, ils éliminent toute action de dosage ou de mélange entre produits. Pas de date de péremption.

Facile à utiliser et à transporter, les tests NARK®II permettent d'identifier 28 substances.

## Mallettes NARK®II

Référence	Caractéristiques
NARK200MK	Mallette 130 tests (2 btes de test 1 & 5, 1 bte de test 2, 3, 4, 7, 8, 10, 11, 12, 15 + neutralisateur)
NARK200IK	Mallette internationale 130 tests (1 bte de test 1, 2, 3, 4, 5, 7, 8, 10, 11,12, 13, 14, 15 + neutralisateur)
NARK200CD	Mallette douanes 50 tests (1 bte de test 1, 4, 7, 10, 15)
NARK200MEG	Mallette 50 tests (1 bte de test 1, 4, 7, 11, 15)
NARK24PAK	Mallette 24 tests (4 tests 1, 11, 15 + 6 tests 5, 7)
NARK200PK	Mallette 16 tests (2 tests 1, 2, 3, 4, 5, 7, 11, 15 + neutralisateur)
NARK200BK	Mallette 6 tests (portable, fixation ceinture) (2 tests 5, 7, 15 + neutralisateur)

## Tests NARK®II

Référence	Test	Caractéristiques
NARK2001	01	Alcaloïdes d'opium (10)
NARK2002	02	Héroïne, morphine (10), confirmation du 01
NARK2003	03	Barbituriques (10)
NARK2004	04	LSD (10)
NARK2005	05	Marijuana, Hashish, THC (10)
NARK2006	06	Neutralisateur en bouteille (30ml)
NARK200N	00	Neutralisateur (boite de 10)
NARK2007	07	Cocaïne salts (HCL), cocaïne base (crack) (10)
NARK2008	08	Méthadone (10)
NARK2009	09	PCP & méthaqualone (10)
NARK20010	10	Codéine, héroïne, oxycodone (10)
NARK20011	11	Toute héroïne (10)
NARK20012	12	Talwin (pentazocine) (10)
NARK20013	13	Ephédrine (10)
NARK20014	14	Valium, Rohypnol, kétamine (10)
NARK20015	15	Méthamphétamine & MDMA (10)
NARK20019	19	Alcaloïdes narcotiques (10)
NARK20020	20	Marijuana (graines et plante) (10)
NARK20021	21	GHB (5)
NS20150		Buvard cocaïne (50)



NS20150

Tel:01 39 13 59 85 - Fax:01 39 13 70 07 - [www.gbr-criminalistique.com](http://www.gbr-criminalistique.com)

**CATALOGUE GENERAL 2012**

# MARK® II Progressive System of Drug Identification



Initiate progressive field testing with the Marquis Reagent, Test 01. Note color(s) and proceed to the next reagent indicated for that substance. Example: Heroin generates a purple in Test 01. Next, go to one of the confirming tests 02, 10 or 11. Heroin is presumptively identified in Test 11 after a dark green color is generated following the breakage of the right ampoule. Note: Squares without color indicate no color develops in that stage of the test. For amplified instructions, reference NARK® II operator's manual.

	01 Marquis	02 Nitric Acid	03 Dille-Koppanyi	04 LSD Reagent (Erich's)	05 Duquenois-Lovine	07 Scott Reagent (modified)	08 Methuone	09 PCP	10 Special Opiates	11 Heroin Mecke's (modified)	12 Talin	13 Ephedrine	14 Valium, Melypod & Methcathinone	15 Meth-amphetamine	19 Mayer's Reagent	20 KN (Fast Blue Salts) Reagent	21 GHB Reagent
Amphetamines	Orange																
Barbiturates	White																
Benzocyclohex	Orange								Blue								
Cocaine	White					Blue											
Cocaine	Blue	Orange				Blue											
DMT	Yellow	Yellow															
Ephedrine											Blue						
GHB																	Green
Heroin	Purple	Yellow							Green	Green							
Ketamine													Purple				
LSD	Orange	Orange		Purple					Blue								
MDA	Orange	Yellow							Green								
MDMA	Purple	Yellow							Green	Purple							
Mescaline	Orange	Pink							Orange								
Methadone	White																
Methamphetamine	Orange	Yellow															
Methcathinone																	
Methcathinone	Orange																
Methcathinone	White																
Methcathinone	Orange																
MMDA	Orange	Orange															
Morphine	Blue	Orange							Blue								
Oxycodone																	
PCP	White																
Pelargonin	Yellow	Orange															
Ribupropyl																	
Talin											Yellow						
Valium																	